Exporting the project's KML

File menu

Phase Manager allows you to export the axes and areas of a drawing, in the KML georeferenced format.

To do so, go the *File* menu then *Export KML.*

Then choose the drawing from which the areas will be exported:



Then choose a target directory where the KML file will be exported, then click on *Save*:



Projet Linéaire
12 impasse Bernard Lyot
85 000 LA ROCHE-SUR-YON
Tél. : +33(0) 2 22 44 52 52
support@projetlineaire.com