Blue stripes beyond the limits of the drawing

“I don't understand why in my deliverables there are blue stripes beyond the limits of the drawing.”

Phase Manager uses built-in print formats that are ISO-compliant (A, B, C, etc.).

The blue stripes mark the extra space available once Phase Manager has adjusted the drawing to the limits (in the dimension that allows it, horizontally or vertically, depending on the orientation chosen). These stripes are not ouputed to print.

Projet Linéaire
12 impasse Bernard Lyot
85 000 LA ROCHE-SUR-YON
Tél. : +33(0) 2 22 44 52 52
support@projetlineaire.com