



The screenshot displays the Phase Manager software interface with a yellow background and a construction crane illustration at the bottom. The interface is divided into several panels:

- Projet en cours:** Displays project details for "D mo SIG testt".
  - Nom:** D mo SIG testt
  - Description:** VRD
  - Responsable:** Fabien GABORIAU
  - D but:** Fin
  - Derni re sauvegarde:** 01/01/1970 01:00
  - Dossier:** D:\Projet Lineaire\Support\01 - Phase Manager\A-Documentation\Pr parati...
  - Taille:** 0.0 Mo
- Plan:** Shows the Phase Manager logo and the text "Le phasage travaux *DYNAMIQUE*".
- Langue:** Features a language dropdown menu set to "fr" and three icons for home, folder, and refresh.
- Workspace:** Shows a file explorer view with the path "D:\Projet Lineaire\Support..." and a list of project items:
  - D mo SIG biennale
  - D mo SIG final
- Version:** Displays "Phase Manager version : 4.0.1" and "La version est   jour." with a refresh icon.