Phase Manager installation

In this section:

- Setup files download
- Prerequisites
- Connection to a Network license
- Standalone license installation and activation
- Installation and Network license activation
- USB license installation and activation
- Updating to Phase Manager 7

Projet Linéaire
12 impasse Bernard Lyot
85 000 LA ROCHE-SUR-YON
Tél. : +33(0) 2 22 44 52 52
support@projetlineaire.com