

# **GIS management**

Create phasing

#### In few words

Phase Manager allows you to build your phasing books over standard or satellite maps, georeference your PDF plans on the maps, and import your zones and axes from a KMZ file.

#### Maps

Phase Manager now allows you to create phasing books over standard or satellite maps.

Simply search for an address to display the corresponding map, using the search field on the map.

For example below, we have searched for "Toulouse" and we selected the detailed satellite view:





## Maps types

The selector below the search field allows you to choose the type of map (options: Satellite or Map) and whether or not to display details - street names and places (options: Detailed/with Names or Uncluttered/without Names). For example, if you change the map type to Map without Name, this is what you will get:

Create phasing		
Drawings	Manage Areas/Axes shapes	Connected objects
Drawings		Zoom
Detailed satellite vi	• + - / + Map	⊙ <b>Q</b> 12.2
➤ Search and layers		PARXXX
Toulouse	Search	No X
Map view without name		- Aller
		116-6
A AND		
		121V-C
Jo be	Je ta	and les
AN A	PACK A	Link -
		MANA C
Eursor coordinates[ lon : 1.5286	5762100028 lat: 43.6099711848674 ]	

## Map adjustment

To fine-tune your map position it is possible to :

- 1/ Move it: by clicking and dragging it using the mouse wheel button.
- 2/ Use the zoom button (or the mouse wheel)



You can also use : the wheel to zoom in or out quickly, and Alt-Wheel to zoom more precisely.



Note: the image quality is optimal on rounded levels: for example 15.0% or 16.0%.

#### 3/ Perform a map rotation

Activate the orientation tool by checking the box next to the zoom buttons Click on the red arrow at the top right of the map:



It then changes colour to a lighter red :



Using the mouse wheel button, it is then possible to click and rotate the map. When the rotation is complete, click the arrow again to exit the rotation mode:



Projet Linéaire 12 impasse Bernard Lyot 85 000 LA ROCHE-SUR-YON Tél. : +33(0) 2 22 44 52 52 support@projetlineaire.com



Your map thus positioned, you can define your print areas.

## Geo-referencing a PDF drawing

Geo-referencing a PDF drawing is very simple: once the drawing is imported, all you have to do is to locate two points and then specify their location on the map:

- distances measured on the map will then be automatically calculated,
- it also allows you to perform clipping on this background drawing.

## Example of geo-referencing

Proceed to the import of a drawing (for example here the 'Demo.svg Project' drawing delivered with your Phase Manager installation, then validate by clicking on Next in the right top corner until step 3.

The drawing is displayed again with the placement options at the bottom left of the screen. Click on *Automatic* :

Options:					
Affichage :	Drawing	Мар			
Placement :	Manual	Automatic San			
Localisation :	Existant	Plan			Ŧ
Opacity					
0 0.1	0.2	0.3 0.4	0.5 0.6	0.7 0.8	0.9 1

A message indicates that two points must be placed on the map; we will click here on the centres of the left and right roundabouts, successively:



A new window indicates that the corresponding points must now be placed on the map:

🗞 Precise placement	×						
Message	i						
Automatic placement helps to choose a geographical position for you drawing.							
Please select two points on the drawing.							
	ок						

In the window that appears next, we will search for "joseph cugnot carquefou", then click on the centers of the roundabouts, in the same order (left, then right):





On the next screen, Phase Manager has superimposed the plan on the map:



Note: by clicking on the Manual Placement button, you can move the map background more finely, and if necessary zoom or rotate it, for an optimal adjustment:



After saving the georeferenced plan (always using the save check mark), the plan is displayed in the Create Phasing window. The measurement tool can now be used to measure real distances on the drawing:





## Importing a KML

On the maps it is possible to draw areas and axes, but it is also possible to import them from a KMZ file exported from Google Earth. This is simply done by means of the KML import button located in the *Manage Areas/Axes shapes* tab:

Create phasing		
Drawings	Manage Areas/Axes shapes	Connected objects
Areas and axes	Print area	Viewing Show areas Show Areas/Axes names
		Show axes Show KP

To test it: search for "montreal willibrord" and set the zoom level to 15.

On the right side of the map, you can visualize the river and its surroundings along with the Richard Park :





Download the "Import zone pour projet SIG.kmz", then click on the KML import button and navigate to the KMZ file to open it:



The imported zones are then created at the Richard Park location:





## **Displaying the MAP in backgroung (V6 feature)**

Georeferenced plans can now display GIS mapping behind and beyond the plan as well.

For this, two new tools are at your disposal to activate this display possibility and to manage the opacity.



A piece of cake as presented in this animation:



Create phasing												+	<b>→</b> ?	₽ x
Drawings Manage Areas/Axes	shapes Connected objects									e i		2		
Drawings	Zoom									Name		Visible Caté	aorie	
Projet Demo.par-		Set a scale								▼ Liste des zo	ones			
										Installatio	ons principales		-	
Search and layers										installation	ons principales		-	
	3									Installati	ons secondaires		•	
										Chaussée	e giratoire		*	
			1-44	317						Mur			*	
													-	
										GirNor	rd : zone des tr		-	
	The states of th	a da la		Ne.						Called and de te			-	
	VI CO AND -	0.10 KM		4) G	1					GINO	u : zone des ti			
	)/ <i>P</i>		N			Second Second				GirNord : zone compl			•	
	H A		23	T		1				GirEst	: zone des trott		*	
	10 A.									GirEst	: zone complète		*	
										GirOue	est : zone des tr		*	
										GirOue	est : zone comp		*	
										Terre-	plein central		*	
										- ~ /				
											Tist	A Avic A	Area .	
ursor coordinates[ lon : -1.4832103202752533 lat: 4	7.296071505858656 ]			and the second							) nek everyening		HICO .	
Gantt chart Tasks Connected objects	on selected drawing													
	Area Eilter					Tacks								
Name (ID)	Start End 27/02	/2024	15 1 42	*		18565		Ŧ	E \$					
🔻 📒 Projet Demo ()				*	Advanced Filte	r Task	field • C							
Sous-projet par défaut (PM-00001) - De	Between Strict 27/02		15 🕌 1 42	w		Style	par défaut 💌	Live Vie	Remove live	e view filter				
							2019						2020	
	Name (PM)	Start (PM) 🔻	End (PM)	Apr	May	Jun	Jul	Aug	Sep	Oct	Nov	Dec	Jan	Feb
	▼ Projet Demo	17/04/2019	21/02/2020											
	▼ Sous-projet par défaut	17/04/2019	21/02/2020											
	Phase 1 : Giratoire Nord	17/04/2019	21/06/2019				+							
	Démolition bordures et navés	22/05/2019	24/05/2019	- 1										<u> </u>
	Démolition bordures et pavés	22/05/2019	24/05/2019											
	Fraisage et dégrappage du bord	27/05/2019	29/05/2019		_									
	Fraisage et dégrappage du bord	27/05/2019	29/05/2019											
	Elargissement chaussée + fouilles + canalisations	30/05/2019	31/05/2019											
	Elargissement chaussée + fouilles + canalisations	30/05/2019	31/05/2019											
	Services, enrobages et remblayages des fouilles + str	05/06/2019	07/06/2019				+							<u> </u>
	Services, enropages et remblayages des fouilles + str	07/06/2019	07/06/2019			-	+					+		<u> </u>
	Pose de bordures et pavés	07/06/2019	07/06/2019											
	Réglage terre végétale	11/06/2019	11/06/2019			*	+ +					-		
	Réglage terre végétale	11/06/2019	11/06/2019											
	Fraisage de chaussée	12/06/2019	13/06/2019			1								