

Step 5 - Adding polyline


On any phasing book, it is important to integrate, to improve reading, pedestrian paths, the direction of traffic of cars or trains. To do this, you can use the polyline.

First of all, you will add the traffic lane on the south side.

Create phasing


Adding a connected object

In the Create phasing interface, click on the “**Connector objects**” tab and select the object you want to add.



1. Polyline	2. Polygon
3. Circle	4. Ellipse
5. Rectangle	6. Square
7. Text	8. Image


Polyline

Click on the button .

Draw your polyline (here the traffic lane in superposition of the southern roadway), point by point with the left click. Once the last point has been positioned, exit the plot mode with a right-click.



In the options that appear on the right click, you can specify which arrow to display in the case of a one-way traffic lane



For more readability, it is possible to change the style of the polyline: just hover over it and right-click on one of its segments, then choose **Settings** . Here we will set those parameters:

Propriété d'un objet

Representation
Spread
Properties

General

Plan
Drawing

Geographical position
lat,lng
Z-index
3

☒ Visible
☐ Locked
☐ perpetual

Graphics

#669996

☐
☐

Border


☐ Transparent
☒ Arrondir les sommets

Thickness
8

Properties of a connected object

To rename the connected objects, they must be localized on the map.

To do this, go to the **Connected objects on selected drawing** tab, of the bottom menu of the Create phasing window, and use the visibility checkmarks to locate your connected object. Click on Edit to open the properties window.




Here we rename the polyline located at the top to **“Traffic North lane Phase 5”**:


Connected objects management

To create the North lane path, you will duplicate the polyline. Select it then do a **Ctrl-C** followed by a **Ctrl-V**.

The original polyline and its copy are superimposed. Move the new polyline to the north lane :



Click on the polyline to select it then move its control points to adjust it to the North lane:




You will now rename both polylines to locate them more easily.

Create phasing


Adding a connected object

In the Create phasing interface, click on the **“Connector objects”** tab and select the object you want to add.




1. Polyline	2. Polygon
3. Circle	4. Ellipse
5. Rectangle	6. Square
7. Text	8. Image


Polyline

Click on the button .

Draw your polyline (here the traffic lane in superposition of the southern roadway), point by point with the left click. Once the last point has been positioned, exit the plot mode with a right-click.



In the options that appear on the right click, you can specify which arrow to display in the case of a one-way traffic lane



For more readability, it is possible to change the style of the polyline: just hover over it and right-click on one of its segments, then choose **Settings** . Here we will set those parameters:

Propriété d'un objet

Representation
Spread
Properties

General

Plan
Drawing

Geographical position
lat,lng
Z-index
3

☒ Visible
☐ Locked
☐ perpetual

Graphics

#669996

☐
☐

Border


☐ Transparent
☒ Arrondir les sommets

Thickness
8

Properties of a connected object

To rename the connected objects, they must be localized on the map.

To do this, go to the **Connected objects on selected drawing** tab, of the bottom menu of the Create phasing window, and use the visibility checkmarks to locate your connected object. Click on Edit to open the properties window.



Here we rename the polyline located at the top to **“Traffic North lane Phase 5”**:

Connected objects management

Click on OK, then repeat the operation with the second polyline to rename it “Traffic South lane Phase 4”.

You can now go to [step 6 of this tutorial](#) !